

MIYOTA

UNIVERSAL MASTERPIECE BORN IN JAPAN

MADE IN JAPAN

METAL MOVEMENT

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT

CALIBRE NO. 82S5


AUTOMATIC MOVEMENT WITH FRONT VIEW SKELETON

A) DISPLAYS AND BUTTONS

B) WINDING THE MAINSPRING

C) SETTING THE TIME

A) DISPLAYS AND BUTTONS



B) WINDING THE MAINSPRING

Automatic winding watch can also be hand wound by turning the crown clockwise in Normal position. Wind several times clockwise. It will start to move naturally.

C) SETTING THE TIME

1. Pull the crown out to the 1st Click Position.
2. Turn the crown to set hour and minute hands.
3. After the time has been set, push the crown back to the Normal position.

These specifications might be changed without prior notice.

CITIZEN WATCH CO., LTD.

MIYOTA

诞生于日本的世界通用机械机芯
日本制造
金属机芯

MIYOTA机芯操作手册

型号 82S5


自动机械机芯（半镂空）

A) 显示和按钮

B) 上发条

C) 校时

A) 显示和按钮



B) 上发条

当柄头在正常位置时，手表也可通过顺时针转动柄轴手动上条
手动上条的话一般转几下，就开始走针。

C) 校时

1. 将柄轴拨到第一档位。
2. 转动柄头可调整时针和分针到正确时间。
3. 然后将柄轴推回原位置

上述数值如有变更恕不另行通知

CITIZEN WATCH CO., LTD.