

Operation Guide 5696

ENGLISH


You can also find information about operational procedures at the CASIO website.

<https://support.casio.com/global/en/wat/model/5696/>



EN-1

About This Manual



- Depending on the model of your watch, display text appears either as dark figures on a light background, or light figures on a dark background. All sample displays in this manual are shown using dark figures on a light background.
- Button operations are indicated using the letters shown in the illustration.
- Each section of this manual provides you with the information you need to perform operations in each mode.
- Note that the product illustrations in this manual are intended for reference only, and so the actual product may appear somewhat different than depicted by an illustration.

EN-2

Contents

About This Manual.....	EN-2
Watch Features.....	EN-5
Configuring Time and Date Settings.....	EN-6
To configure the digital time settings.....	EN-6
To configure date settings.....	EN-8
To adjust the analog time setting.....	EN-9
Selecting a Mode.....	EN-10
Alarm.....	EN-12
To configure alarm and hourly time signal settings.....	EN-12
To stop the alarm.....	EN-15
To test the alarm.....	EN-15
Dual Time.....	EN-16
To configure Dual Time settings.....	EN-16

Stopwatch.....	EN-19
To measure elapsed time.....	EN-19
Main Indicators.....	EN-20
Specifications.....	EN-21

Watch Features

- ◆ **Dual Time**
Dual Time lets you keep track of the current time in another time zone in addition to your current location's time.
- ◆ **Alarm**
- ◆ **Stopwatch**

You can also find information about operational procedures at the CASIO website.




<https://support.casio.com/global/en/wat/model/5696/>

EN-4


EN-5

Configuring Time and Date Settings

To configure the digital time settings



- In the Timekeeping Mode, hold down (A) for at least two seconds. This causes the seconds to flash on the display.
- Press (A) to move the flashing in the sequence shown below to select a setting.



PM indicator

EN-6


- Use (B) to change the selected setting.

Screen	This setting item:
35	Reset the second to 00 • 30 to 59 seconds: Adds 1 to minutes
P 10:08	Change the hour or minute • Holding down (B) changes the current selection at high speed.
12 H	Toggle between 12-hour (12H) and 24-hour (24H) timekeeping


- Press (A) to return to the Timekeeping Mode. The setting operation is complete when the screen stops flashing.

- The watch returns to the Timekeeping Mode automatically if you do not perform any button operation for one or two minutes in the setting screen.

To configure date settings



- In the Date Mode, hold down (A) for at least two seconds. This causes the month to flash.
- Use (A) to select the setting item you want to change.



Month

Day

Day of the week



- Press (B) to change the currently selected setting.
 - Holding down (B) scrolls the setting at high speed.

EN-8

- Press (A) to return to the Date Mode. The setting operation is complete when the screen stops flashing.

- The watch will automatically return to the Timekeeping Mode if you do not perform any button operation for one or two minutes.
- The Auto Calendar automatically distinguishes between months of different lengths. You do not need to change the setting except for leap years or after replacing the watch's battery.

To adjust the analog time setting




- In any mode, press (C) to advance the time setting by 20 seconds.
- Holding down (C) advances the setting at high speed.

EN-9

Selecting a Mode

- Press (B) to change the mode.



* SU: Sunday MO: Monday TU: Tuesday WE: Wednesday TH: Thursday FR: Friday SA: Saturday

You can also find information about operational procedures at the CASIO website.



<https://support.casio.com/global/en/wat/model/5696/>

EN-10

EN-11

Alarm

When the Daily Alarm is turned on, the alarm sounds for 20 seconds at the preset time each day. When the Hourly Time Signal is turned on, the watch beeps every hour on the hour.


- Note that the Daily Alarm and the Hourly Time Signal operate based on the digital time setting.
- The watch returns to the Timekeeping Mode automatically if you do not perform any button operation for one or two minutes in the Alarm Mode.

To configure alarm and hourly time signal settings

- In the Alarm Mode, hold down (A) for at least two seconds. This causes the alarm hour digits to flash.



- Use (A) to select the setting item you want to change.



- Press (B) to change the currently selected setting.


- Holding down (B) scrolls the setting at high speed.



EN-12

EN-13

- While the alarm/hourly time signal setting is selected, each press of (B) cycles the setting in the sequence shown below.



- Press (A) to return to the Alarm Mode. The setting operation is complete when the screen stops flashing.

To stop the alarm

Press (A) or (B) to stop the alarm after it starts to sound.

To test the alarm

Hold down (B) in any mode to sound the alarm.

EN-14

EN-15


Dual Time

Dual Time lets you set the current time in another time zone different from the time in your current time zone.

- This means that your watch can be set up to display three times: digital time, analog time, and Dual Time.
- The seconds count of the Dual Time is synced with the digital time seconds.

To configure Dual Time settings

- In the Dual Time Mode, hold down (A) for at least two seconds. This causes the hour digits to flash.



EN-16

EN-17


- While the 12/24-hour timekeeping screen is displayed, press (B) to toggle between 12 and 24.



- Press (A) to return to the Dual Time Mode. The setting operation is complete when the screen stops flashing.

- The watch will automatically return to the Timekeeping Mode if you do not perform any button operation for one or two minutes.

- Use (A) to select the setting item you want to change.



- Press (B) to change the currently selected setting.

- Holding down (B) scrolls the setting at high speed.




EN-18

EN-19

Stopwatch


The Stopwatch Mode lets you measure elapsed time. The range of the stopwatch is 59 minutes, 59.99 seconds.



To measure elapsed time



Main Indicators



Number	Name	See
1	PM indicator	EN-6
2	Alarm Mode	EN-12
3	Alarm on indicator	EN-14
4	Stopwatch Mode	EN-19
5	Dual Time Mode	EN-16
6	Hourly time signal on indicator	EN-14

EN-20

Specifications

Accuracy:

±30 seconds per month average.

Analog Timekeeping:

Hour, minute (moves every 20 seconds)

Digital Timekeeping:

Time: Hour, minute, second, switchable between 12-hour and 24-hour formats
Date: Month, day, day of the week (auto calendar)

Alarm:

Setting units: Hour, minute
Beeper: 20 seconds
Hourly time signal: Watch beeps every hour on the hour.

Dual Time:

Hour, minute, second, switchable between 12-hour and 24-hour formats

EN-21

Stopwatch:

Measuring units: 1/100 second
Measuring capacity: 59 minutes, 59.99 seconds (60 minutes)
Measuring modes: Elapsed time, cumulative elapsed time

Other:

Auto return to Timekeeping Mode; Test alarm

Battery:

SR920W x 1
Battery life: Approximately 3 years
Conditions:
- Alarm: Once (20 seconds)/day

Specifications are subject to change without notice.

EN-22